



Never adjust inside of the crown (use fit-checker "black")

	Cementation Science	
	Zirconium Oxide	Lithium disilicate glass-ceramic (Emax, Celtra and etc.)
Etching/Cleaning (inside crown)	Ivoclean *** (rinse out after 20 sec. and dry)	5% HF Acid or Ivoclean *** (rinse out after 20 sec. and dry)
Conditioning/ Silanization (inside crown)	Monobond® Plus (blow thin after 60 sec.)	Monobond® Plus (blow thin after 60 sec.)
Cementation System (on preparation)	Multilink • Automix Unicem	Multilink • Automix SpeedCEM Viva Glass® CEM

***See Ivoclean on Youtube

Modern Dental Technology Laboratory • 8 Maralbo Avenue E, Winnipeg, MB R2M 5G7

Phone number: 204-805-2589

email address: Moderdentallab@hotmail.com